

DNP

Photo Imaging

DIGITAL PHOTO PRINTER

DNP Printers

Macintosh OS X

Driver Installation

CONTENTS

1. DNP Printer Driver Instructions for Mac OS X

Acknowledgments.	3
Purpose.	3
Installing the Driver	3
Turning On the Printer	6
Uninstalling the Driver	7
Troubleshooting.	7

DNP Printer Driver Instructions for Mac OS X

Acknowledgments

The information contained in this document represents the current view of DNP Imagingcomm America Corp. on the issues discussed as of the date of publication. Because DNP Imagingcomm America Corp. must respond to changing market conditions, it should not be interpreted to be a commitment on the part of DNP Imagingcomm America Corp. DNP Imagingcomm America Corp. cannot guarantee the accuracy of any information presented after the date of publication.

This document is for informational purposes only.

DNP Imagingcomm America Corp. MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, AS TO THE INFORMATION IN THIS DOCUMENT.

Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of DNP Imagingcomm America Corp..

DNP Imagingcomm America Corp. may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from DNP Imagingcomm America Corp., the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property.

DNP Imagingcomm America Corp. • 4524 Enterprise Dr. NW • Concord, NC 28027 • USA

© 2000-2015 DNP Imagingcomm America Corp. All rights reserved.

Purpose

The DNP printer driver will provide printing functionality similar to the Microsoft Windows printer Driver for the DS-Series and RX-Series printers.

The following OS versions and processor architectures are supported:

Mac OS 10.11 (El Capitan)

Mac OS 10.10 (Yosemite)

Mac OS 10.9.5 (Mavericks)

All executable modules should be 32/64-bit Intel binaries and support:

- ☐ Intel 32-bit processor architecture (i386)
- ☐ Intel 64-bit processor architecture (x86_64)

Installing the Driver

This document includes instructions for installing the printer drivers for DS/RX printers on Mac OS X.



Attention

Before You Begin: !!!PLEASE ACTIVATE THE I-SERIAL FUNCTION IN YOUR DS620 PRINTER!!!!

If the DS/RX printer is connected to your computer, make sure it is turned OFF.

Go to **System Preferences > Print & Fax**. If a DS/RX series printer is listed, delete it.

1. From your browser, navigate to the following site <http://dnpphoto.eu>.
2. Download the **Mac OS-X Driver for DS620/DS40/Ds80/RX1/DS620A/ DS80DX** file.
3. Navigate to where you downloaded the file. Decompress the **DNP Install.zip** file.

4. In the next window, double-click the **DNP DS Printer Drivers** icon.




Figure 1. DS Printer Drivers Icon



Note

Depending on which driver you are installing, you may see a DS printer device or a RX printer device.

5. The installer will begin. Click **Continue**.



Figure 2. Installer

6. Read the important information on the following screen. When you are done, click **Continue**.



Figure 3. Important Information

7. Read the License Agreement on the following screen. When you are done, click **Continue**.




Figure 4. License Agreement

8. You will be prompted to accept the license agreement terms. Click **Agree**.




Figure 5. Agree

9. In the next window, click **Install**.



Figure 6. Install

10. If your Mac operating system is password protected, enter your password when prompted. Click **OK**.



Figure 7. Password

11. The installation will begin.

12. When the installation is complete, you will receive the message "Install Succeeded." Click **Close**.



Figure 8. Install Succeeded

You have now installed the DS Printer Drivers on a Mac operating system.



Note

Upon installing the DS Printer Drivers, the DNP ICC profiles are also installed. To change the ICC profiles, please see the Mac Driver User Guide.

Turning On the Printer

1. If the printer is not already plugged into the USB port, do so now.
2. Turn the printer ON.
3. The printer should be added as a device automatically in about 1 minute.



Attention

Do NOT use the + sign to add the printer. In this case, you may have another instance of the DS Series printer in the printer list.

Uninstalling the Driver

Follow this procedure to uninstall the printer drivers for DS/RX printers on Mac OS X.

1. Navigate to where you downloaded the **Mac OS-X Driver for DS620/DS40/DS80/RX1/DS620A/ DS80DX** file.



Note

If you no longer have the above mentioned file, please follow steps 1 - 3 in the Installing the Driver section on page 3.

2. Decompress the **DNP Install.zip** file.
3. In the next window, double-click the **DNP Uninstaller** icon.
4. The uninstall process begins.
5. Navigate through any subsequent windows that are displayed.

Troubleshooting

- ☐ Make sure the printer is connected to the USB port and turned ON. The LEDs on the printer should indicate a “Ready” status. (For more information on this, consult the DS/RX Printer User Manual.)

- ☐ If the printer is added, but you cannot print:
 1. Turn the printer OFF. Go to **System Preferences > Print & Fax** and delete any DS/RX Printers listed.
 2. Turn the printer ON and wait for the printer to add itself as a device.

If the printer does not automatically add itself to the printer list, use the + sign to add it in the **System Preferences > Print & Fax** dialog box.

DNP Imagingcomm America Corporation