



SL620

Installation and Quick Start Guide

Exclusively for DNP Printers

Summary

For more details, please visit www.dnpphoto.eu website
to download the Photo Editing Software User Guide.

Chapter 1

Warning	5
Warning on power connection	5
For the customers in Europe.....	5

Chapter 2

Installation	6
Box content.....	6
Fixing DS-Tmini to DS620 printer.....	7

Chapter 3

Quick Start	12
Starting SL620	12
Change of software language by default	12
Make a print order	14
Shutdown the SL620	17

Chapter 4

Troubleshooting	18
-----------------------	----

Warning

Chapter 1

To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.

To avoid electrical shock, do not open the DS-T mini and DS-Printer covers. Refer servicing to qualified staff only.

THIS EQUIPMENT MUST BE EARTHED.

To disconnect the main power, unplug the AC IN connector.

Warning on power connection

Use a proper power cord for your local power supply.

1. Use the approved Power Cord (3-core mains lead) / Appliance Connector / Plug with earthing-contacts that conforms to the safety regulations of each country if applicable.
2. Use the Power Cord (3-core mains lead) / Appliance Connector / Plug conforming to the proper ratings (Voltage, Ampere).

For the customers in Europe

This product shall not be used in the residential area.

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

FIT Engineering S.r.l. hereby declares that this DS-Tmini is in compliance with the essential requirements and other relevant provisions of Directives 2004/108/EC and 2006/95/EC.

If you want to dispose this product, do not mix with general household waste.

There is a separate collection system for used electronics products in accordance with legislation under the WEEE Directive and is effective only within European Union. For details, consult your dealer.










Installation

Chapter 2


Box content

The box contents:


		
DS-Tmini	Power cord	USB cable
		
Rear Bracket with 2 x M3 screws	Router holder	Side brackets 4 x M3 screws
	(This document)	
Netgear Router	Explanation booklet	

Fixing DS-Tmini to DS620 printer


1. Loose the two lower screws on printer back side.
2. Position the router holder slots between screws and DS620 backplane with a top to bottom movement.
3. Gently tight the two screws.




4. Remove the two top screws on DS620 back panel.
5. Position the rear bracket with caution to the reference slots (keep the supplied M3 screws for later use).
6. Fix the bracket by tightening the two screws on DS620 back plane.




7. Insert the router into the router support.




8. Use the opening lever to open the lock of the DS620 and pull out the mechanism unit by approximate 10 cm.
9. Gently position the DS-Tmini on top of the DS620.
10. Slide the DS-Tmini backwards until the two front hooks engage with DS620 top cover.
11. Gently close the printer mechanism.




12. Use the two M3 screws supplied with the rear bracket to fix it to the back side of the DS-Tmini.



13. Connect the two side brackets to the sides of the DS-Tmini. Please note that they are left and right side and they are not the same.



14. Connect the USB cable from the DS-Tmini to the DS620 printer.
15. Connect the network cable to the DS-Tmini and the router (port 1 to 4, NOT the blue port).
16. Connect the power supply cable to the DS-Tmini.
17. Connect the power supply cable to the DS620 printer.
18. Connect the power supply adaptor to the Netgear Router.



Quick Start

Chapter 3

Make sure all power supply cables (Printer, Router and DS-Tmini) are connected.

Starting SL620

- 1) Switch on the DS620 printer.
- 2) Load media into the printer (please refer to DS620 Start-up Guide).
- 3) Switch on the DS-Tmini (Switch ON button is on the rear side).
 - ➔ After a few minutes the Photo Editing Software will automatically start running. The software will display only products that can be printed with connected printer and loaded media.



Note: If the DS 620 Printer is not connected, the software will display the following message:

No products available. Please verify that the printers are properly connected to the system.

refresh


- ➔ When the printer is connected to the system, the above message will disappear automatically within a few seconds and then the software will display the products window as per the connected printer.

Change of software language by default

- 1) Enter into Main Panel by touching in sequence the lower left and right corners of the monitor.



- 2) Click on **settings** button



- 3) Choose "Settings" > "Language"



Available Languages	
Czech	Japanese
English	Polish
Finnish	Portuguese
French	Romanian
German	Russian
Greek	Spanish
Hungarian	Ukranian
Italian	

- **Available languages:** The Photo Editing Software both editing & admin settings are available from the above list of languages.

- **Administrator Language:** select language to be used as default language for settings. You need to restart the software to have new language in operation.
- **Language:** select language to be used for user workflow.
- **Select language:** if set to yes, user will be able to choose workflow language from the selection set with "Available languages" button.


Make a print order

This is the Workflow of creating and printing Single Sided Print product.

- 1) Select Prints.



- 2) Select media where images are located, as an example a folder with images.



- 3) Select images. By pressing "+" or "-" sign the print quantity can also be entered at this stage.




- 4) Select product and paper finish type.




- 5) Edit print quantity, crop and enhance images, add text.



- 6) Add Text. To change text dimensions and rotation click and drag on rotation button.



7) Order summary.



The screen displays the title "Order summary" at the top. Below it is a table with two columns: "Product" and "Quantity". The first row contains the text "Print 30x15 Groovy" and the number "8". To the right of the quantity is a circular icon with a checkmark. Below the table are three empty horizontal lines. At the bottom right of the table area is a button with a plus sign and the text "add products". At the very bottom of the screen are three navigation buttons: "back" (left arrow), "cancel" (X icon), and "next" (right arrow).

8) Insert Customer name.



The screen displays the title "Fill in your information" at the top. Below it is a label "name:" followed by a text input field. At the bottom of the screen is a full QWERTY keyboard layout. At the very bottom of the screen are three navigation buttons: "back" (left arrow), "cancel" (X icon), and "next" (right arrow).

9) Press "next" to finish the order.

Shutdown the SL620

- 1) Enter into Main Panel by touching in sequence the lower left and right corners of the monitor.



- 2) Click on **Computer shutdown** button



- 3) Wait until DS-Tmini will automatically switch OFF
- 4) Switch off the DS620 printer.
- 5) Disconnect power cables.

Troubleshooting

Chapter 4

For any technical issue(s) and question(s), please contact DNP PIE support team at:

support@dnpphoto.eu

For more details, please visit www.dnpphoto.eu website
to download the Photo Editing Software User Guide.